LCD Projection TV

OWNER'S MANUAL

MODEL: RU-48SZ40

Please read this manual carefully before operating your set.
Keep the manual with the TV for future reference.
Record model number and serial number of the set.
See the label attached on the back cover and relay the information to an authorized service center if you require service.

LG Electronics U.S.A., Inc.

Downloaded from www.Manualslib.com manuals search engine

WARNING
RISK OF ELECTRIC SHOCK
DO NOT OPEN

WARNING:

TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:

TO PREVENT FIRE OR SHOCK HAZARDS, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

POWER CORD POLARIZATION:

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

ATTENTION: POUR ÉVITER LES CHOCS ÉLECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA BORNE CORRESPONDANTE DE LA PRISE ET POUSSER JUSQU'AU FOND.

NOTE TO CABLE/TV INSTALLER:

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the National Electric Code (U.S.A.). The code provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of the cable entry as practical.

REGULATORY INFORMATION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAUTION:

Do not attempt to modify this product in any way without written authorization from LG Electronics Corporation. Unauthorized modification could void the user's authority to operate this product.
The responsible party for this device compliance is:
LG Electronics U.S.A., Inc
1000 Sylvan Avenue, Englewood Cliffs, NJ 07632
1-201-816-2000
http://www.lgusa.com

Downloaded from www.Manualslib.com manuals search engine

IMPORTANT SAFETY INSTRUCTIONS

Important safeguards for you and your new product

Your product has been manufactured and tested with your safety in mind. However, improper use can result in electrical shock or fire hazards. To avoid defeating the safeguards that have been built into your new product, please read and observe the following safety points when installing and using your new product, and save them for future reference.

Observing the simple precautions discussed in this manual can help you get many years of enjoyment and safe operation that are built into your new product.

This product complies with all applicable U.S. Federal safety requirements, and those of the Canadian Standards Association.

1. Read Instructions

All the safety and operating instructions should be read before the product is operated.

2. Follow Instructions

All operating and use instructions should be followed.

3. Retain Instructions

The safety and operating instructions should be retained for future reference.

4. Heed Warnings

All warnings on the product and in the operating instructions should be adhered to.

5. Cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

6. Water and Moisture

Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool.

7. Accessories, Carts, and Stands

Do not place this product on a slippery or tilted surface, or on an unstable cart, stand, tripod, bracket, or table. The product may slide or fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

8. Transporting Product

A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.

PORTABLE CART WARNING

9. Attachments

Do not use attachments not recommended by the product manufacturer as they may cause hazards.

10. Ventilation

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

11. Power Sources

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

12. Power-Cord Polarization

This product is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

13. Power-Cord Protection

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

(Continued on next page)

Downloaded from www.Manualslib.com manuals search engine

IMPORTANT SAFETY INSTRUCTIONS

(Continued from previous page)

14. Outdoor Antenna Grounding

If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded to provide protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code (U.S.A.), ANSI/ NFPA 70 provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

Example of Grounding According to National Electrical Code Instructions


Ground Clamp
Antenna Lead in Wire
Antenna Discharge Unit (NEC Section 810-20)
Grounding Conductor (NEC Section 810-21)
Electric Service Equipment
Ground Clamps
Power Service Grounding Electrode System (NEC Art 250, Part H)

Fig. 1

NEC - National Electrical Code

15. Lightning

For added protection for this product (receiver) during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

16. Power Lines

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

17. Overloading

Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

18. Object and Liquid Entry

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

19. Servicing

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

20. Damage Requiring Service

Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

a. If the power-supply cord or plug is damaged.

b. If liquid has been spilled, or objects have fallen into the product.

c. If the product has been exposed to rain or water.

d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.

e. If the product has been dropped or the cabinet has been damaged.

f. If the product exhibits a distinct change in performance.

21. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

22. Safety Check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

23. Wall or Ceiling Mounting

The product should be mounted to a wall or ceiling only as recommended by the manufacturer. The product may slide or fall, causing serious injury to a child or adult, and serious damage to the product.

24. Heat

The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

Downloaded from www.Manualslib.com manuals search engine

Table of Contents

Safety Warnings 2
Important Safety Instructions 3-4
Function Status Indicators 6

Step 1. Hook Up TV

Rear Connections Panel 7
Front Connections Panel 8
ANT/Cable Service Hookup 9
Cable Box Connections 10
VCR Connections 11
DVD Player 12
RGB/DVI-HD/STB Input 13
RGB-PC/DVI-PC Input 14
External Stereo Connections 15
Speaker Connection 16
Monitor Out Setup 17
Remote Control Functions In TV Mode 18-19
On-Screen Displays 20
Front Panel Controls 21

Step 2. Customize your TV's Features

SETUP Menu Options

EZ Scan (Channel Search) 22
Channel Add/Del/Surf Setup 23
Channel Label Setup 24
Main Picture Source Selection 25
PIP (Picture-in-Picture) 26
PIP (Picture-in-Picture) Operation 27
POP (Picture-out-of-Picture) 27
Twin Picture 28

VIDEO Menu Options 29-30
AUDIO Menu Options 31-32
TIME Menu Options

Auto Clock Setup 33
Manual Clock Setup 34
TV Turn Off Time Setup 35
TV Turn On Time Setup 36
Sleep Timer Setup 37
Auto Off 38

SPECIAL Menu Options

Aspect Ratio 39
Captions Setup 40
Caption/Text Mode Selection 41
On-Screen Menus Language 42
EZ Demo (Menu Review) 43

LOCK Menu Options

Parental Lock Setup 44-46

Step 3. Miscellaneous

Programming the Remote 47
Programming Codes 48-59
Maintenance 50-51
Troubleshooting 52-53
Glossary 54-55
Product Specifications 56
Notes 57-58
Warranty 59-60

Setup Checklist

Step 1. Make all equipment and source connections.
See pages 6-17.

Step 2. Install batteries in remote control and do a channel search.
See page 22.

Step 3. Adjust and fine-tune TV features and options to your preference.
See contents above.

Note: Design and specifications are subject to change without prior notice.

Downloaded from www.Manualslib.com manuals search engine

Function Status Indicators

Lamp indicator, operation indicator, and temperature indicator located below the front panel controls, reveal the operating status of the LCD projection TV.



Operation Indicator	Off	TV is not connected to power outlet.
	Red	Power Cord is connected, TV is in standby mode.
	Green	On
	Orange (flashing)	Preparing operation in standby mode.
Lamp Indicator	Orange	Projection lamp is reaching the end of its life and needs to be replaced with a new lamp.
	Red (flashing)	There is a problem with the lamp or around it. Contact an authorized service center.
	Green (flashing)	The lamp cover is not closed.
Temperature Indicator	Orange	The projection TV is overheating.
	Red	The projection TV shut down due to overheating.
	Red (flashing)	The projection TV shut down, check the cooling fan.

Downloaded from www.Manualslib.com manuals search engine

Rear Connections Panel

Connecting cables and external equipment to your TV.



RF Connector: Antenna
Used to connect analog cable or antenna signals to the television, either directly or through your cable box.

S-VIDEO In
A connection available with some high-end equipment that provides even better picture quality for Video 2.

Video 1 or 2
Connects the video signals from various types of equipment.

Left/Right Audio
Used for stereo sound from various types of equipment.

Monitor Out
Connects to a second TV or Monitor.

EXTERNAL SPEAKER (8 ohm output)
Connect to the external speaker(s). For further information, refer to Speaker manual.

PC and HD-STB Inputs
Used to connect from a PC source or HD-STB Satellite system.

Y, Pb, Pr DVD Component Video and HD Component Video
Some top-of-the-line DVD players use what is called "component video," for extremely accurate picture reproduction. *Refer to your DVD manual for further information.*

PC and HD-STB Audio Input
Used for audio connections from a PC source or HD-STB Satellite system.

Variable Audio Out
Used to connect either an external amplifier, or add a sub-woofer to your surround sound system.

Audio Center Mode In
Connect to external Dolby Digital Center "preamp output."

Mini glossary

JACK	A connection on the back of a TV, VCR, or any other A/V device. This includes the RF jack and the Audio/Video jacks that are color-coded.
SIGNAL	Picture and sound traveling through cable, or over the air, to your television screen.

Downloaded from www.Manualslib.com manuals search engine

Front Connection Panel

There are four jacks on the right front side behind the screen on your projection TV that make connecting Audio/Video devices like video games and camcorders very simple.

The jacks are like those found on the back jack connection panel. This means that most equipment that connects to those types of jacks on the rear jackpack, may be connected to the front connection panel.

To use the front jacks as the signal source, select them using Main Input menu as described on page 25. They will be named "Front Video" in the Main Input menu.

If you select either Front Video or Front S-Video, the Front audio inputs are automatically selected as well.

If you're connecting a video game device, make sure to change the picture settings with the EZ Picture option in the Video menu (see page 29).





S-Video
A connection available on some very high-end equipment that provides better picture quality than video input.

Video
Connects the video signals from any piece of equipment.

Left/Right Audio
Used for stereo sound from various types of equipment.

Mini glossary

A/V CABLES	Audio/Video cables. Three cable connector—Right audio (red), Left audio (white), and Video (yellow). A/V cables are used for stereo playback of videocassettes and for higher quality picture and sound from other A/V devices.
A/V DEVICE	Any device that produces video or sound (VCR, DVD, cable box, or television).

Downloaded from www.Manualslib.com manuals search engine

ANT / Cable Service Hookup

1 Connect an antenna and/or cable service to your TV as shown.

2 Turn to page 22 to do a channel search with EZ Scan for Ant/Cable connection(s).



If you receive your RF signal through an antenna that is several years old and connects with two small prongs, you will need to purchase a 300 to 75 ohm adapter. It should be available from your local electronics dealer.

We recommend using a 75 ohm cable for your antenna connections in order to prevent interference.

For best signal reception, it is recommended to have your Antenna professionally adjusted.

Downloaded from www.Manualslib.com manuals search engine

Cable Box Connections

1 Locate the output jack on the back of your cable box. Connect this to the Antenna jack on the back of your TV.

Or find the composite video and audio jacks on the back of your cable box, and connect them following the instructions provided with your equipment.
This can be combined with any other equipment you may want to hook up.



If you're using a cable box, leave the TV on channel 3 or 4 and use your cable box to change channels.

Downloaded from www.Manualslib.com manuals search engine

VCR Connections

1 Locate the Antenna jack on the back of your TV. Connect this to RF out jack on the back of your VCR.

Or, find the composite video and audio jacks on the back of your VCR, and connect them following the instructions provided with your equipment.

You may connect either the composite video or the S-Video cables to your TV. (Do not connect both the composite and the S- Video cables. In the event that you connect both composite and the S-Video cables, only the S-Video will work.)



To hear stereo sound from cable or your VCR, you will need to connect A/V cables as well as the wire that runs from the VCR to your TV.

If you want to receive your signals on Channel 3 or 4, locate the Out to TV jack on your VCR. Connect a cable from the Out to TV jack to the Antenna In jack on the back of your TV.

After connecting external equipment to the TV, don't display a still picture for a long time on the screen. Doing so may damage the TV screen.

Downloaded from www.Manualslib.com manuals search engine

DVD Player

1 Find the audio and component or S-Video jacks on the back of your DVD Player and connect them following the instructions provided with your equipment.

Some high-end DVD players use a picture reproduction system called "component video." If your DVD player has component output, use the connectors marked "Component 1/2" on the jack panel. Please refer to your DVD manual for proper installation.



Component 1 (or 2) Input

Y	P_B	P_R
1920X1080i		
1280X720p		
720X480p		
720X480i		

- **Component Input ports**
  Connect DVD player jacks to Monitor Component input jacks as indicated below.

Component input jacks on the Monitor	Y	P_B	P_R
Video output jacks on DVD player	Y Y Y Y	Pb B-Y Cb P_B	Pr R-Y Cr P_R

Mini glossary

COMPONENT VIDEO — Some video equipment uses three separate lines (Y, P_B, P_R) to more precisely reproduce images. Your video equipment manual will explain how this relates to your equipment.

Downloaded from www.Manualslib.com manuals search engine

RGB/DVI-HD/STB Input

1 Find the audio and Y, P_B, P_R/RGB/DVI jacks on the back of your DBS receiver and connect them following the instructions provided with your equipment.

2 Connect these cables to your TV as shown.





The DTV shows the sharpest picture in 720p mode.

This TV supports HDCP (High-bandwidth Digital Contents Protection) protocol for DVI-DTV (480p, 720p, 1080i) mode.

Select RGB-DTV Source and press ENTER. Use UP/DOWN arrows to select the desired options (V-position/H-position/Phase) and then use LEFT/RIGHT arrows to make appropriate adjustments.

In RGB-DTV mode, V-position/H-position/Phase are not adjustable if you choose either the POP or Twin picture modes.

RGB-HD/STB Input

HD-SET TOP
1920x1080i
1280x720P
720x480P

Signal	Component1	Component2	RGB/DVI-DTV
480i	Yes	Yes	No
480p	Yes	Yes	Yes
720p	Yes	Yes	Yes
1080i	Yes	Yes	Yes

Downloaded from www.Manualslib.com manuals search engine

RGB-PC/DVI-PC Input

1 Find the audio and RGB or DVI jacks on the back of your PC and then connect them following the instructions provided with your equipment.

2 Connect these cables to your TV as shown.



Select RGB-PC Source and press ENTER. Use UP/DOWN arrows to select the desired options (V-position/H-position/V-size/H-size/Phase) and then use LEFT/RIGHT arrows to make appropriate adjustments.

*- **Vertical position, Horizontal position, Vertical size, and Horizontal size**: Based on the input mode (resolution), the adjustment ranges may change.*

*- **Phase**: Removes any horizontal noise and clears up or sharpens the character images. Adjustment range is -15 ~ + 15.*

In DVI-PC mode, adjustments are only Vertical size, and Horizontal size.

In RGB-PC/DVI-PC modes, for POP or Twin screen, V-position/H-position/V-size/H-size/Phase are not adjustable.

Synchronization input form: Signals are separate.

RGB-PC/DVI-PC Input

MODE	Resolution	Horizontal	Vertical
Text	640x350	31.5KHz	70Hz
VGA	640x480	31.5KHz	60Hz
	640x480	37.9KHz	72Hz
	640x480	37.5KHz	75Hz
SVGA	800x600	35.2KHz	56Hz
	800x600	37.9KHz	60Hz
	800x600	48.1KHz	72Hz
	800x600	46.9KHz	75Hz
XGA	1024x768	48.4KHz	60Hz
	1024x768	56.5KHz	70Hz
	1024x768	60.0KHz	75Hz

Downloaded from www.Manualslib.com manuals search engine

External Stereo Connections

Connect Left/Right Variable Audio Output to an external Audio Amplifier System.

1 Locate both Variable Audio Out jacks on the back of your TV and the Left/Right audio input jacks on the back of your stereo's amplifier.

2 Connect these jacks, making sure that they are connected correctly (red=Right, white=Left.)

3 Adjust the sound on your stereo, according to directions provided with the amplifier.



Downloaded from www.Manualslib.com manuals search engine

Speaker Connection

Connect the external speakers to TV's "EXTERNAL SPEAKER" jack.
Be sure to connect the positive "+" wire to the "+" input and
the negative "-" wire to the "–" input.



Downloaded from www.Manualslib.com manuals search engine

Monitor Out Setup

1 Your TV has a special signal output capability which allows you to hook up a second TV or monitor.

2 Just connect the second TV or monitor to the MONITOR OUT Audio/Video jacks located on the back of your TV. See the Operating Manual of the second TV or monitor for further details regarding that device's input settings.



Component 1 - 2, RGB-DTV/PC, and DVI-DTV/PC input sources for main picture cannot be used for Monitor Out.

Downloaded from www.Manualslib.com manuals search engine

Remote Control Functions in TV Mode



LIGHT
Illuminates the remote control keys.

TV/VIDEO
Selects: Analog, Video1, Video2, Front video, Component1-2, RGB, and DVI input sources.

FRONT
Selects the front video signal if a device, such as a camcorder or game player, is connected to the front video input jack.

MUTE
Switches the sound on or off

THUMBSTICK
Allows you to navigate the on-screen menus and to adjust the system settings and preferences, by moving to an option with ◄ ▲▼ ► and selecting the highlighted option with ◉.

MENU
Brings up the main menu to the screen.

PIP
Toggles between PIP, POP (Picture-out-of-Picture) and Twin picture mode.

FREEZE
Captures and freezes the currently-viewed main picture in PIP mode.

MODE
Selects the remote operating mode: TV, VCR, DVD, Cable, HDSTB, or Audio. Select other operating modes, for the remote to control external devices.

COMP/DVI
Selects: Component1-2, RGB, and DVI input sources.

SURF
Scrolls the Surf channel list.

SLEEP
Selects the amount of time before your TV turns itself off automatically.

EXIT
Clears all on-screen displays and returns to TV viewing from any menu.

PIP INPUT
Selects the input source for the sub picture.

SWAP
Switches the picture from PIP, POP, or twin picture to the main screen.

Downloaded from www.Manualslib.com manuals search engine

Remote Control Functions in TV Mode



NUMBER KEYPAD
For direct channel selection and programming functions.

ENTER
When in the menu system and other on-screen displays, selects highlighted options.

VOLUME UP/DOWN
Increases/decreases the sound level.

RATIO
Changes the screen format or aspect ratio.

CC
Selects a closed caption mode for displaying captioning information if available on program.

VIDEO
Adjusts the factory preset picture according to the room.

RECORD, PAUSE, REW, FFWD, PLAY, STOP
Control the functions on your VCR.

SAP
Selects: Mono, Stereo, and SAP.

POWER
Turns your TV or any other programmed equipment on or off, depending on mode.

FLASHBK
Tunes to the last channel viewed.

CHANNEL UP/DOWN
Scrolls through available channels in EZ Scan memory.

AVL
To keep an equal volume level of each channel.

AUDIO
Selects the sound appropriate for the program's character.

SKIP
Playing CDs: Selects songs.
Playing DVDs: Selects movie chapters.

PIPCH+
Changes to next higher PIP channel.

PIPCH-
Changes to next lower PIP channel

Downloaded from www.Manualslib.com manuals search engine

On-Screen Displays

This page describes your on-screen display and information banner options.



Main Channel Display
Displays current channel number.

Channel Label
If a channel label has been set, then it will appear here.

PIP Display
This display appears when PIP is active.

Mute
Appears when sound is muted.

Volume
Volume level is displayed while adjusting the sound.

Time
Appears if the Enter button is pressed on remote control.

Downloaded from www.Manualslib.com manuals search engine

Front Panel Controls



1 Operation indicator. (See page 6).

2 Lamp indicator. (See page 6).

3 Temperature indicator. (See page 6).

4 POWER

5 MENU

6 ENTER (Same as ENTER button on your remote control)

7 VOLUME UP / DOWN

8 CHANNEL UP / DOWN

See menu pages for instructions on using the on-screen menus.

The POWER, CHANNEL, TV/VIDEO, and VOLUME buttons work just as they do on your remote control.

Downloaded from www.Manualslib.com manuals search engine

EZ Scan (Channel Search)

Automatically finds analog channels available through ANT IN input, and stores all active over-the-air and cable channels in memory on the channel list.



1 Refer to pages 7-15 to connect external equipment to your TV. If you have not done so, plug in your TV to a standard 120V 60Hz power outlet.



2 If you have not done so, remove the back of the remote and install two AA batteries. Make sure batteries are properly installed (check the +/– symbols).

3 With the remote control in hand, press the POWER button to turn your TV on.

4 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu.

5 Press ENTER or the RIGHT arrow button to access the Setup menu.

6 Use the UP/DOWN arrows to select EZ Scan.

7 Press ENTER or the Right arrow button to start the EZ Scan channel search.



Downloaded from www.Manualslib.com manuals search engine

Channel Add / Del / Surf Setup



Create two different types of channel lists in memory: "Custom list" and "Surf list".
A custom list can be created by toggling each channel on or off with ◉ (Enter).
Once a channel is highlighted, you will be able to see whether the channel is currently added or deleted by referring to the small window at the top-left corner of the screen.
You can create your own Surf list with up to 16 channels. It appears at the bottom-left corner of the screen.
Press the Surf button on the remote control when a channel is highlighted to add or delete the channel in the Surf list.

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu.

2 Press ENTER or the RIGHT arrow button to access the Setup menu.

3 Use the UP/DOWN arrows to select Ch.Edit and then press ENTER or the right arrow button.

4 You will now see a screen filled with channel numbers and a preview picture. Use the UP/DOWN and LEFT/RIGHT arrows to select a channel, then use ENTER to Hide or Show it. Press SURF to add the channel to the Surf List.

5 Press EXIT to save and return to TV viewing or press MENU to save and return to the previous menu.



Downloaded from www.Manualslib.com manuals search engine

Channel Label Setup





Choose preset labels for your channels.

Use Channel +/- on your remote control in the Ch. Label menu to select a channel for labeling, then choose a suitable label for the channel by pressing ◎ to attach the label to the selected channel.

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu.

2 Press ENTER or the RIGHT arrow button to access the Setup menu.

3 Use the UP/DOWN arrows to select the Ch. Label option.

4 Press ENTER or the RIGHT arrow to access the Ch. Label menu.

5 You will now see a menu filled with Labels and a preview screen. Use channel UP/DOWN button on your remote to select a channel to Label.

6 Use the UP/DOWN and LEFT/RIGHT arrows to select the appropriate label for the channel or to select a blank label section to use to create a channel name.

- Use the UP/DOWN/LEFT/RIGHT arrows and press ENTER to set the Label to the selected channel.
- Use the UP/DOWN/ LEFT/RIGHT arrows and press SURF to edit channel name. Eight blank channel sections are available.
  Use the LEFT/RIGHT arrows to select a word position and use the UP/DOWN arrows to change the letter. Press SURF to save.

7 Repeat 5 and 6 steps until all channels are Labeled.

8 Press EXIT to save and return to TV viewing.



Downloaded from www.Manualslib.com manuals search engine

Main Picture Source Selection

Changes the picture source for the main screen so you can watch your off-air TV, cable TV, VCR, DVD, or any other devices that are connected to your TV.



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu.

2 Press ENTER or the RIGHT arrow button to access the Setup menu.

3 Use the UP/DOWN arrows to select Main Input.

4 Press ENTER or the RIGHT arrow to access the Main Input menu, then use the UP/DOWN arrow button to select a source. Your Main picture source options are: Ant/Cable, Video 1, Video 2, Front Video, Component 1, Component 2, RGB-DTV, RGB-PC, DVI-DTV, or DVI-PC.

5 Press EXIT to save and return to TV viewing or press the LEFT arrow to save and return to the previous Menu.



Downloaded from www.Manualslib.com manuals search engine

PIP (Picture-in-Picture)

PIP lets you view 2 different inputs (sources) on your monitor screen at the same time. One source will be large, and the other source (PIP) will show a smaller inset image.

Watching PIP

Press the PIP button to show the sub picture.
Each press of PIP changes the PIP options as shown below.



PIP Source Selection

Changes the picture source for the Picture-in-Picture image so you can watch your off-air TV, cable TV, VCR, or any other devices that are connected to your TV.

Using the menu

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Setup menu.
2. Press ENTER or the RIGHT arrow button to access the Setup menu.
3. Use the UP/DOWN arrows to select the Sub Input option.
4. Press ENTER or the RIGHT arrow to access the Sub Input menu, then use the UP/DOWN arrow button to select the source. Your choices are: Ant/Cable, Video 1, Video 2, Front Video.
5. Press EXIT to save and return to TV viewing or press the LEFT arrow to save and return to the previous Menu.



Do not display a fixed image on the screen for long periods of time. Doing so may cause image burn-in.

Not all sources are available for PIP.

Using the PIP INPUT button

1. Use the PIP INPUT button to select the input source for the sub picture.
Each time you press PIP INPUT button, you toggle between Ant/Cable, Video 1, Video 2, and Front Video.

Downloaded from www.Manualslib.com manuals search engine

PIP (Picture-in-Picture) Operation

Selecting PIP Channels

1 Select the Ant/Cable source with the PIP INPUT button.

2 Use the PIPCH-/PIPCH+ button to select a channel for the sub picture.

Swapping Pictures

Press the SWAP button.
Each time you press the SWAP button, you switch the Main and PIP pictures.



Main Picture *Sub Picture*

Moving the Sub Picture

In the PIP mode, each press of the UP/DOWN/LEFT/RIGHT arrow buttons will move the sub picture to a different position on the screen.

POP (Picture-outside-Picture)

Use POP to search the pictures for all the programmed channels one-by-one on the 3 PIP screen display, while the main screen remains the current channel.

1 Press PIP on the remote control with the PIP image on the screen to activate POP (Picture-outside-Picture) mode.
The pictures of all the programmed channels are searched with the 3 PIP screen, as shown to the right.

- Press SWAP, to enlarge the selected channel being searched on the PIP screen to view it on the Main screen. (Main and sub pictures can be swapped if main picture source is Ant/Cable.)

2 Press the EXIT button to exit POP mode.

Run EZ Scan channel search before using POP mode.

Downloaded from www.Manualslib.com manuals search engine

Twin Picture

Twin Picture splits the screen into 2, allowing 2 pictures to be shown on the TV screen at the same time. Each source is given half the screen.

Watching Twin Picture

1. Press the PIP button on the remote control in POP mode to activate twin picture mode. Select the Ant/Cable source with the PIP INPUT button.
2. Use the PIPCH-/PIPCH+ button to select the desired channel for the sub picture.

Swapping Pictures

Press the SWAP button.
Each time you press SWAP, you switch the PIP and Main screen pictures.



Selecting an Input Signal Source for Sub Picture

Use the PIP INPUT button to select the input source for the sub picture. Each time you press PIP INPUT, you toggle between Ant/Cable, Video 1, Video 2, and Front Video.

Downloaded from www.Manualslib.com manuals search engine

Video Menu Options

Adjust the picture's appearance to suit your preference and viewing situations.



You can manually adjust the levels for the picture quality settings, such as Contrast, Brightness, Color, etc.

You can also select a preset value from the EZ Picture menu based on the category of the program.

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Video menu.

2 Press ENTER or the RIGHT arrow button to access the Video menu.

3 Use the UP/DOWN arrows to select one of the following options: EZ Picture (Off, Daylight, Normal, Night Time, Movie, Video Game, and Sports), Contrast, Brightness, Color, Sharpness, Tint, Color Temperature (Warm, Medium, Cool), or Cinema. Press ENTER or the Right arrow button.

4 Use the LEFT/RIGHT arrows to adjust the option to your preference (Contrast, Brightness, Color, Sharpness, Tint).
Use the UP/DOWN arrows to set the option to your preference (EZ Picture, Color Temperature, Cinema).

5 Press EXIT to save and return to TV viewing or press the ENTER button to save and return to the previous menu.



Downloaded from www.Manualslib.com manuals search engine

Video Menu Options



- **Contrast** Adjusts the difference between the light and dark levels of the picture. Press the right arrow button to activate adjusting.
- **Brightness** Adjusts the white or light level of the overall picture.
- **Color** Adjusts the intensity of all colors.
- **Sharpness** Adjusts the level of crispness in the edges between the light and dark areas of the picture. The lower the level, the softer the image.
- **Tint** Adjusts the balance between the red and green levels.
- **EZ Picture** Offers the following preset options for the picture settings.
  Off Lets you adjust the picture manually to your preferences.
  Daylight Increases the levels of all picture settings to fit daylight conditions.**Normal** Restores the picture levels to their original settings.
  Normal Restores the picture levels back to their original settings.
  Night Time: Increases the levels of all picture settings to fit daylight conditions.
  Movie Adjusts Video settings to enhance Movie viewing. Contrast and Sharpness levels are lowered so that the picture looks warm and soft.
  Video Game Sets the picture settings to the levels that are more suitable to enjoy games. Color, Contrast and Sharpness levels are lowered to reduce the amount of glare.
  Sports Sets the picture settings to the levels that are more suitable to view sporting events. Contrast and Color levels are raised so that an action scene appears clear and brilliant.
- **Color Temperature** Adjusts levels of all colors in the TV picture: Warm, Medium, or cool.
- **Cinema** Adjust the TV for the best picture for watching movies. To use Cinema, you must choose the Movie option in EZ Picture.

Downloaded from www.Manualslib.com manuals search engine

Audio Menu Options

Adjust the sound to suit your taste and room situations.

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Audio menu.

2 Press ENTER or the RIGHT arrow button to access the Audio menu.

3 Use the UP/DOWN arrows to select one of the following options: EZ Sound Rite, EZ Sound, Balance, Treble, Bass, Front Surround, or TV Speaker. Press ENTER or the RIGHT arrow button.

4 Use the LEFT/RIGHT arrows to adjust the option to your preference (Balance, Treble, Bass).

Use the UP/DOWN arrows to select the option (EZ Sound Rite, EZ Sound, Front Surround, or TV Speaker)

5 Press EXIT to save and return to TV viewing or press ENTER button to save and return to the previous menu.



Downloaded from www.Manualslib.com manuals search engine

Audio Menu Options (Contd.)



- **EZ SoundRite** Scans for changes in sound level during commercials, then adjusts the sound to match the current audio level of the TV program you are watching. You can also use this function with AVL button.
- **EZ Sound** Chooses the sound options manually.
  Off Lets you adjust the Audio menu sound options manually.
  Normal Restores the sound settings to their original levels.
  Stadium Stresses high frequency sounds and front surround sound to create the sensation you would experience in a stadium.
  News Increases high frequency sounds to emphasize the human voice.
  Music Increases both high and low frequency sounds to stress the sounds of musical instruments.
  Theater Stresses both high and low frequency sounds, in addition to the front surround sound, to create the sensation you would experience in a theater.
- **Balance** Adjusts the sound more to the left or right for the TV speakers.
- **Treble** Increases or decreases the higher frequency sounds from the TV speakers. Increases in treble, for example, make voice or string sounds stand out.
- **Bass** Increases or decreases the lower frequency sounds from the TV speakers.
- **Front Surround** Increases the front surround sound to create more open and expanded sound.
- **TV Speaker** Allows you to toggle the TV internal speakers Stereo, Center or off. If you want to use your external hi-fi stereo system, turn off the internal TV speakers. However, you may use the internal TV speakers as a center speaker to create a surround effect.

Downloaded from www.Manualslib.com manuals search engine

Auto Clock Setup

Sets the time automatically from the PBS broadcast signal.

The PBS channel signal includes information for the correct time.

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu.

2 Press ENTER or the RIGHT arrow button to activate the Time menu.

3 Use the UP/DOWN arrow button to choose Auto Clock, then press ENTER or the RIGHT arrow button to activate the Auto Clock option. Use the LEFT/RIGHT arrow button to make your auto clock selection.

- Use the UP/DOWN arrow button to set the PBS channel.
- Time Zone - Selects the time zone for your viewing area.
- Daylight Savings - Sets Daylight Savings Auto, On, or Off, depending on whether or not your viewing area observes Daylight Savings.
- If you select Auto Clock, use the UP/DOWN arrow button to choose On or Off.

4 Press EXIT to save and return to TV viewing or press the ENTER button to save and return to the previous menu.



Downloaded from www.Manualslib.com manuals search engine

Manual Clock Setup

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu.

2 Press ENTER or the RIGHT arrow button to activate the Time menu.

3 Use the UP/DOWN arrow button to choose Manual Clock, then press the RIGHT arrow to activate the Manual Clock menu.

4 Use the LEFT/RIGHT arrows button to make your Manual Clock selection. Your choices are: Year, Date and Time.

5 Use the UP/DOWN arrows to set the Year, Date, and Time.

6 Press EXIT to save and return to TV viewing or press the ENTER button to save and return to the previous menu.



Downloaded from www.Manualslib.com manuals search engine

TV Turn Off Time Setup

Set up a time for your TV to automatically turn itself off each day.

Off Time function overrides On Time function if they are both set to the same time.



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu.

2 Press ENTER or the RIGHT arrow button to activate the Time menu.

3 Use the UP/DOWN arrows to choose Off Time then press the RIGHT arrow to activate Off Time selection menu.

4 Use the UP/DOWN arrows to choose On.

5 Use the LEFT/RIGHT arrows to select each Off Time option.

6 Use the UP/DOWN arrows to set the hours and then the minutes.

7 Press EXIT to save and return to TV viewing, or press the ENTER button to save and return to the previous menu.

To cancel Off Time function, use the UP/DOWN arrow button to select Off in step 4.



Downloaded from www.Manualslib.com manuals search engine

TV Turn On Time Setup

Set up a time for your TV to automatically turn itself on each day.

Unless a button is pressed within two hours after the TV is turned on by the On time function, the TV will automatically turn itself off.



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu.

2 Press ENTER or the RIGHT arrow to activate the Time menu.

3 Use the UP/DOWN arrows to choose On Time, then press the RIGHT arrow to activate the On Time menu.

4 Use the UP/DOWN arrows to choose On.

5 Use the LEFT/RIGHT arrows to select in turn the On Time menu options: Time, Channel, and Volume.

6 Use the UP/DOWN arrows to set Time, Channel, and Volume at turn on.

7 Press EXIT to save and return to TV viewing, or press the ENTER button to save and return to the previous menu.

To cancel On Time function, use the UP/DOWN arrow button to select Off in step 4.



Downloaded from www.Manualslib.com manuals search engine

Sleep Timer Setup

Select a preset time to turn your TV off automatically.



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu.

2 Press ENTER or the RIGHT arrow button to activate the Time menu.

3 Use the UP/DOWN arrows to choose Sleep Timer then press the RIGHT arrow to access the Sleep Timer menu.

4 Use the UP/DOWN arrows to choose a preset turn off time.

5 Press EXIT to save and return to TV viewing, or press the ENTER button to save and return to the previous menu.



If you turn the TV off after setting sleep timer, the setting will be erased. Set it again if necessary.

Downloaded from www.Manualslib.com manuals search engine

Auto Off

If there is no input signal, the TV can be set up to switch to standby mode automatically after 10 minutes.

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Time menu.

2 Press the ENTER or the RIGHT arrow button to go to the Time menu.

3 Use the UP/DOWN arrow button to choose Auto Off then press the RIGHT arrow button to access the Auto Off menu.

4 Use the UP/DOWN arrows to choose On or Off.

5 Press EXIT button to save and return to TV viewing, or press the MENU button to save and return to the previous menu.



Downloaded from www.Manualslib.com manuals search engine

Aspect Ratio

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Special menu. Or press RATIO button to instantly access the Aspect Ratio menu.

2 Press ENTER or the RIGHT arrow button to activate the Special menu.

3 Use the UP/DOWN arrows to choose Aspect Ratio.

4 Press ENTER or the RIGHT arrow button to move into the Aspect Ratio selection menu. Use the UP/DOWN arrow buttons to select the proper ratio for your viewing environment:

- 4:3 - Choose when you want to view a picture with an original 4:3 aspect ratio, with black bars appearing at both the left and right sides.
- 16:9 - Choose when you want to adjust the picture horizontally, in a linear proportion to fill the entire screen. (Useful for viewing 4:3 formatted DVDs.)
- Horizon - Choose when you want to adjust the picture in a non-linear proportion, that is, more enlarged at both sides, to create a spectacular view.
- Zoom1 - Choose when you want to view the picture without any alteration. However, the top and bottom portions of the picture will be cropped.
- Zoom2 - Choose when you want the picture to be altered, both horizontally extended and vertically cropped. The picture taking a halfway trade off between alteration and screen coverage.

5 Press EXIT to save and return to TV viewing or press the ENTER button to save and return to the previous menu.

For RGB-PC/DVI-PC source, you can select either 4:3 or 16:9 aspect ratios.
For RGB-DTV/DVI-DTV (720p, 1080i) or Component 1-2 (720p, 1080i) sources, you can select either 4:3, 16:9 or Zoom1-2 aspect ratios.

Aspect ratio is changed to 16:9 automatically for 720p or 1080i formats from component input1/2, RGB, or DVI sources.

After connecting external equipment to the TV, don't display a still picture for a long time on the screen. Doing so may damage the TV screen.



Lets you choose the way that an analog picture with a 4:3 aspect ratio is displayed on your TV 16:9 aspect ratio TV screen. When you receive an analog picture with a 4:3 aspect ratio on your 16:9 TV, you need to specify how the picture is to be displayed according to your preference.



Downloaded from www.Manualslib.com manuals search engine

Captions Setup



Using the menu

1. Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Special menu.
2. Press ENTER or the RIGHT arrow button to activate the Special menu.
3. Use the UP/DOWN arrows to choose Captions, then press ENTER or the Right arrow button.
4. Use the UP/DOWN arrow buttons to make your caption selection. Your choices are: Off, EZ Mute, and On.
5. Press EXIT to save and return to TV viewing or press the ENTER button to save and return to the previous menu.



Using the CC button

1. Use the CC button to select captions.

   Each press of the CC button changes the caption option; Off, EZ Mute, and On.
   Note: Select a Caption/Text mode on the next page, afterward Captions Setup will be complete.
   EZ Mute shows the selected captions option (if available on program) when the TV sound is muted.
2. Press EXIT to save and return to TV viewing.

Downloaded from www.Manualslib.com manuals search engine

Caption/Text Mode Selection

Select a closed caption mode for displaying captioning information if provided on the program.

Captions displays information at any position on the screen usually the program's dialog.

Text displays information, usually at the bottom portion of the screen and is used for a data service, generally not program related.



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Special menu.

2 Press ENTER or the RIGHT arrow button to activate the Special menu.

3 Use the UP/DOWN arrows to choose Caption/Text, then press ENTER or the Right arrow button.

4 Use the UP/DOWN arrow buttons to make your caption selection. Your choices are: CC 1, CC 2, CC 3, CC 4, Text 1, Text 2, Text 3, or Text 4.

5 Press EXIT to save and return to TV viewing or press the ENTER button to save and return to the previous menu.



Downloaded from www.Manualslib.com manuals search engine

On-Screen Menus Language

Select your preferred language for the menus: English, Spanish, or French.

1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Special menu.

2 Press ENTER or the RIGHT arrow button to activate the Special menu.

3 Use the UP/DOWN arrows to choose Language.

4 Press ENTER or the RIGHT arrow button to move into the Language selection menu. Use the UP/DOWN arrow button to select the language you wish to use for your on-screen menus.

5 Press EXIT to save and return to TV viewing or press the ENTER button to save and return to the previous menu.



Downloaded from www.Manualslib.com manuals search engine

EZ Demo (Menu Review)

Use EZ Demo to scan the features and menu options available on your TV.



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Special menu.

2 Press ENTER or the RIGHT arrow button to activate the Special menu.

3 Use the UP/DOWN arrows to choose EZ Demo, then press ENTER or the RIGHT arrow button to activate EZ Demo.

4 Press EXIT button on the remote to cancel EZ Demo.



Downloaded from www.Manualslib.com manuals search engine

Parental Lock Setup

Lets you set up blocking schemes to block specific channels, program ratings, and external sources.

If the Lock System is active, a password is required to gain access to this menu.



1 Press the MENU button on the remote control, then use the UP/DOWN arrow button to select the Lock Menu.

2 Press ENTER or the RIGHT arrow button to access the Lock Menu.

3 See the next page for more details on your blocking options.



Downloaded from www.Manualslib.com manuals search engine

Parental Lock Setup (Contd.)



4 Use the UP/DOWN arrows to choose from the following Lock Menu options.

- **Lock System**: Activates or disables the blocking scheme you set up previously.
- **Set Password:** Changes the password by keying in a new password twice.
- **Block Ch.**: Blocks any channels that you do not want to watch or that you do not want your children to watch.
- **Movie Rating:** Blocks movies according to the movie ratings limit, so children cannot view certain movies. You can set the ratings limit by blocking out all the movies with the ratings above the specified level. Keep in mind that the movie ratings limit only applies to movies shown on TV, not TV programs, such as soap operas.
- **TV Rating-Children**: Keeps children from watching certain TV programs among only the programs intended for children, according to the ratings limit. This rating does not apply to other TV programs. Unless you block certain TV programs intended for mature audiences in the TV Rating - General menu, your children may view those programs.
- **TV Rating-General**: Blocks certain TV programs that you and your family do not want to watch, based on the ratings.
- **Aux. Block**: Enables you to select a source for blocking among the source devices you have hooked up.



If you forget your password, enter the number, 7777 to release the lock mode.

Downloaded from www.Manualslib.com manuals search engine

Parental Lock Rating Descriptions



TV-Y7 (Children 7 Years & Older): Program is designed for children age 7 and above.

TV-G (General Audiences): Most parents would find this program suitable for all ages.

TV-PG (Parental Guidance Suggested): Program contains material that parents may find unsuitable for younger children.

TV-14 (Parents Strongly Cautioned): Program contains some material that many parents would find unsuitable for children under 14 years of age.

TV-MA (Mature Audience Only): Program is specifically designed to be viewed by adults and therefore may be unsuitable for children under 17.

G (General Audience): Suitable for all ages.

PG (Parental Guidance Suggested): Some program content may not be suitable for children.

PG-13 (Parents strongly cautioned): Some program content may not be appropriate for children under 13.

R (Restricted): Children under 17 requires accompanying parent or adult guardian.

NC-17: Not suitable for persons 17 and younger.

TV-Y (All Children): Program is determined to be appropriate for all children.

X: Adult only.

Blocking Off: Permits all programs.

Downloaded from www.Manualslib.com manuals search engine

Programming the Remote

The remote control is a multi-brand or universal remote control that can be programmed to operate most remote-controllable devices of other manufacturers.

Note: The remote control may not be able to control all models of other brands.

1 Test your remote control.
To find out whether your remote control can operate the device without programming, turn on the device such as a the VCR and press the corresponding MODE button (VCR) on the remote control while pointing at the device. Test the **POWER** and **CH +/-** buttons to see if the device responds properly. If not, the remote requires programming to operate the device.

2 Turn on the device to be programmed. Then press the corresponding MODE button on the remote control.

3 Press the MENU button and the MUTE button simultaneously. Now the remote control is ready to program the code for the corresponding device.

4 There are two ways to find the right code for the device.

A. If you press the **CH +/-** buttons repeatedly, the codes will change one at a time. Press the POWER button after each code change. If the right code is found, the device will turn off.

B. Enter a code number using the number buttons on the remote. The right code numbers for the corresponding component can be found on the following pages.
Again, if the code is correct, the device will turn off when you press the POWER button.

5 Press the MENU button to store the code.

6 Test the remote control functions to see if the device responds properly. If not, repeat from step 2.



Downloaded from www.Manualslib.com manuals search engine

VCRs

Brand	Codes				Brand	Codes				Brand	Codes				Brand	Codes			
AIWA	034				KENWOOD	014	034	039	043	PORTLAND	108				TATUNG	039	043		
AKAI	016	043	046	124		047	048			PULSAR	072				TEAC	034	039	043	
	125	146			LG (GOLDSTAR)	001	012	013	020	QUARTZ	011	014			TECHNICS	031	033	070	
AMPRO	072					101	106	114	123	QUASAR	033	066	075	145	TEKNIKA	019	031	033	034
ANAM	031	033	103		LLOYD	034				RCA	013	020	033	034		101			
AUDIO DYNAMICS	012	023	039	043	LXI	003	009	013	014		040	041	062	063	THOMAS	034			
BROKSONIC	035	037	129			017	034	101	106		107	109	140	144	TMK	006			
CANON	028	031	033		MAGIN	040					145	147			TOSHIBA	008	013	042	047
CAPEHART	108				MAGNAVOX	031	033	034	041	REALISTIC	003	008	010	014		059	082	112	131
CRAIG	003	040	135			067	068				031	033	034	040	TOTEVISION	040	101		
CURTIS MATHES	031	033	041		MARANTZ	012	031	033	067		053	054	101		UNITECH	040			
DAEWOO	005	007	010	064		069				RICO	058				VECTOR RESEARCH	012			
	065	108	110	111	MARTA	101				RUNCO	148				VICTOR	048			
	112	116	117	119	MATSUI	027	030			SALORA	014				VIDEO CONCEPTS	012	034	046	
DAYTRON	108				MEI	031	033			SAMSUNG	032	040	102	104	VIDEOSONIC	040			
DBX	012	023	039	043	MEMOREX	003	010	014	031		105	107	109	112	WARDS	003	013	017	024
DYNATECH	034	053				033	034	053	072		113	115	120	122		031	033	034	040
ELECTROHOME	059					101	102	134	139		125					053	054	131	
EMERSON	006	017	025	027	MGA	045	046	059		SANSUI	022	043	048	135	YAMAHA	012	034	039	043
	029	031	034	035	MINOLTA	013	020			SANYO	003	007	010	014	ZENITH	034	048	056	
	036	037	046	101	MITSUBISHI	013	020	045	046		102	134				058	072	080	101
	129	131	138	153		049	051	059	061	SCOTT	017	037	112	129					
FISHER	003	008	009	010		151					131								
FUNAI	034				MTC	034	040			SEARS	003	00	009						
GE	031	033	063	072	MULTITECH	024	034			010	013	014	017	020					
	107	109	144	147	NEC	012	023	039	043		031	042	073	081					
GO VIDEO	132	136				048					101								
HARMAN KARDON	012	045			NORDMENDE	043				SHARP	031	054	149						
HITACHI	004	018	026	034	OPTONICA	053	054			SHINTOM	024								
	043	063	137	150	PANASONIC	066	070	074	083	SONY	003	009	031	052					
INSTANTREPLAY	031	033				133	140	145			056	057	058	076					
JCL	031	033			PENTAX	013	020	031	033		077	078	149						
JCPENNY	012	013	015	033		063				SOUNDESIGN	034								
	040	066	101		PHILCO	031	034	067		STS	013								
JENSEN	043				PHILIPS	031	033	034	054	SYLVANIA	031	033	034	059					
JVC	012	031	033	043		067	071	101			067								
	048	050	055	060	PILOT	101				SYMPHONIC	034								
	130	150	152		PIONEER	013	021	048		TANDY	010	034							

CATV

Brand	Codes				Brand	Codes				Brand	Codes				Brand	Codes			
ABC	003	004	039	042	GOLDEN CHANNEL	030					065	085	090		SL MARX	030			
	046	052	053		HAMLIN	049	050	055		PIONEER	034	051	052	063	SPRUCER	047	078		
AJIN	112				HITACHI	052	055				076				STARCOM	002	004	008	009
ANTRONIK	014				HOSPITALITY	070	077			POST NEWS WEEK	016				STARGATE	008	030		
ARCHER	005	007	014	024	JERROLD	002	003	004	008	PRUCER	059				SYLVANIA	067			
CABLE STAR	026					009	010	052	069	PTS	011	048	071	072	TADIRAN	030			
CENTURION	092					074					073	074			TAEKWANG	110			
CENTURY	007				LG (GOLDSTAR)	001	106	101	005	PULSAR	100				TAIHAN	105			
CITIZEN	007				M-NET	037				RCA	047				TANDY	017			
COLOUR VOICE	065	090			MACOM	033				REGAL	049	050			TEXSCAN	029	067		
COMBANO	080	081			MAGNAVOX	010	012	064	079	REGENCY	057				TOCOM	039	040	056	
COMTRONICS	019	030			MEMOREX	100				REMBRANT	025				TOSHIBA	100			
DIAMOND	023				MOVIE TIME	028	032			RK	091				UNIKA	007	014	024	
EAGLE	020	030	040		NSC	015	028	038	071	SAMSUNG	102	107	030	068	UNITED CABLE	004	053		
EASTERN	057	062	066			073				SCIENTIFIC ATLANTA	003	011	041	042	UNIVERSAL	005	007	014	024
ELECTRICORD	032				OAK	016	031	037	053		043	045	046			026	027	032	035
GE	072				PANASONIC	044	047			SHERITECH	022				VIEWSTAR	012	015	018	086
GEMINI	008	022	025	054	PARAGON	100				SIGNAL	030					087	088	089	
GI	052	074			PHILIPS	006	012	013	020	SIGNATURE	052				ZENITH	100	114	060	093

Downloaded from www.Manualslib.com manuals search engine

HDSTB

Brand	Codes	Brand	Codes	Brand	Codes	Brand	Codes
ALPHASTAR DSR	123	EUROPLUS	114	MEMOREX	057	STARCAST	041
AMPLICA	050	FUJITSU	017 021 022 027	NEXTWAVE	028 124 125	SUPER GUIDE	020 124 125
BIRDVIEW	051 126 129		133 134	NORSAT	069 070	TEECOM	023 026 075 087
BSR	053	GENERAL INSTRUMENT	003 004 016 029	PACE SKY SATELLITE	143		088 090 107 130
CAPETRONICS	053		031 059 101	PANASONIC	060 142		137
CHANNEL MASTER	013 014 015 018	HITACHI	139 140	PANSAT	121	TOSHIBA	002 127
	036 055	HOUSTON TRACKER	033 037 039 051	PERSONAL CABLE	117	UNIDEN	016 025 042 043
CHAPARRAL	008 009 012 077		057 104	PHILIPS	071		044 045 048 049
CITOH	054	HUGHES	068	PICO	105		078 079 080 086
CURTIS MATHES	050 145	HYTEK	053	PRESIDENT	019 102		101
DRAKE	005 006 007 010	JANIEL	060 147	PRIMESTAR	030 110 111	UNIDEN	135 136
	011 052 112 116	JERROLD	061	PROSAT	072	VIEWSTAR	115
	141	KATHREIN	108	RCA	066 106	WINEGARD	128 146
DX ANTENNA	024 046 056 076	LEGEND	057	REALISTIC	043 074	ZENITH	081 082 083 084
ECHOSTAR	038 040 057 058	LG	001	SAMSUNG	123		091 120
	093 094 095 096	LUTRON	132	SATELLITE SERVICE CO	028 035 047 057		
	097 098 099 100	LUXOR	062 144		085		
	122	MACOM	010 059 063 064	SCIENTIFIC ATLANTA	032 138		
ELECTRO HOME	089		065	SONY	103		

Audio

Brand	Codes	Brand	Codes	Brand	Codes	Brand	Codes
AIWA	014 028 070 096	JVC	004 013 141	PHILIPS	026 112 143 253		147 218
	125 129 139 229	KEC	185 186 187	PIONEER	039 042 043 063	TOSHIBA	137
	230	KENWOOD	038 050 067 089		065 091 093 094	THE	061
AKAI	163		170 171 197 206		115 123 127 250	VICTOR	088 131
ANAM	003 014 017 023		215 222	QUASAR	113	WARDS	089
	059 106 189 216	KOHEL	030	RCA	080	YAMAHA	054 055 066 092
	217 235 236	NAD	045 046	RCX	092		199
BURMECTER	252	LOTTE	014 016 036 098	REALISTIC	103 106		
CARVER	086		100 172 173 174	SAMSUNG	124 145 146 182		
CLARION	199		175 176 177 178		193 194 195 203		
DAEWOO	027 053 060 084		179 180 181 183		204 244 245 246		
	102 148 198 221		201 202 208 213	SANSUI	011 135 138 144		
DENON	015 075 130 143		214 219 223 232	SANYO	019 083 234		
FANTASIA	071		238 240	SCOTT	106 186		
FINEARTS	022	LXI	103	SHARP	031 032 051 052		
FISHER	089 099	MAGNAVOX	111		072 082 117 119		
LG(GOLDSTAR)	001 021 024 029	MARANTZ	002 018 020 025		156 184 199 200		
	087 107 108 110		034 041 081 090		206 209		
	190 191 192 210		097 112	SHERWOOD	005 006 158		
	211 212 239	MCINTOSH	049	SONY	044 045 109 114		
HAITAI	034 035 188 222	MCS	104		118 126 248 249		
HARMAN/KARDON	068	MEMOREX	107	TAEKWANG	012 020 073 074		
INKEL	037 058 062 069	NAD	046		076 077 105 161		
	078 079 095 121	ONKYO	013 040 041 047		162 163 164 165		
	122 149 150 151		048 056 057 132		166 167 168 169		
	152 153 154 155		133 140		205 231 233 242		
	157 158 159 160	OPTIMUS	158		254		
	189 207 222 224	PANASONIC	007 033 064 113	TEAC	010 085 106 136		
	225 226 227 243		142 220 241 251		185 187 237		
	247	PENNEY	104	TECHNICS	101 113 128 134		

DVD

Brand	Codes	Brand	Codes	Brand	Codes	Brand	Codes
APEX DIGITAL	022	MAGNAVOX	013	PHILIPS	013	SONY	007
DENON	020 014	MARANTZ	024	PIONEER	004 026	THOMPSON	005 006
GE	005 006	MITSUBISHI	002	PROCEED	021	TOSHIBA	019 008
HARMAN KARDON	027	NAD	023	PROSCAN	005 006	YAMAHA	009 018
JVC	012	ONKYO	008 017	RCA	005 006	ZENITH	010 016 025
LG	001 010 016 025	PANASONIC	003 009	SAMSUNG	011 015		

Downloaded from www.Manualslib.com manuals search engine

Maintenance

Early malfunctions can be prevented. Please read pages 2, 3, and 4 in the front of the manual and follow the recommendations provided. Careful and regular cleaning can enhance the appearance of your new TV. Be sure to turn the power off and pull the plug out of the power outlet before you begin any cleaning.

SCREEN CLEANING

1. Here's a great way to keep the dust off your screen for a while. Wet a soft cloth in a mixture of lukewarm water and a little fabric softener or dish washing detergent. Wring the cloth until it's almost dry, and then use it to wipe the screen.
2. Make sure the excess water is off the screen, and then let it air-dry before you turn on your TV.

CABINET CLEANING

1. Use a soft cloth with a mild soap solution to wipe the cabinet.
2. Rinse the cloth and wipe the cabinet again.
3. Let the cabinet air-dry before turning the TV on.

WOOD CABINETS

Use a quality wood cleaner and polish. This will protect the TV from dirt and dust, as well as keep the cabinet looking new.

EXTENDED ABSENCE

If you intend to leave your TV dormant for a long time (such as a vacation), it's a good idea to unplug the power cord to protect against possible damage from lightning or power surges. If you use an off-air antenna, you may also want to disconnect it from the back of your TV before leaving.

Downloaded from www.Manualslib.com manuals search engine

PICTURE INTERFERENCE

Even though you may be getting cable service, the signal may be weak, which means the quality of your picture may suffer due to other factors. If there are problems with the image on your TV, consult the Troubleshooting guide on the following pages. You may also want to contact your cable service provider to determine if the problem is from the cable service.

VIDEO GAMES AND OTHER FIXED-PATTERN DISPLAYS

If you use your TV to play video games or for other uses that have single, fixed images, such as a photo-CD player, you should avoid setting the Brightness level too high. If static images, like network identification patterns, are left on the screen for too long, they can leave a permanent impression on the TV screen. You can reduce the chance of this happening by limiting the amount of time you use the fixed-image display, and by reducing the contrast and brightness levels.

If you unplug your TV from a wall power outlet, you may have to reset the clock using the Time menu described earlier.

Downloaded from www.Manualslib.com manuals search engine

Troubleshooting

Some quick and easy tips to fixing problems yourself.

SYMPTOMS	POSSIBLE SOLUTIONS
Snowy picture and unclear sound.	• Check your antenna connection or location. • Check your cable input. • Check to see if the TV/VCR button on your VCR has the TV selected.
Multiple images or 'ghost shadows.'	• Check your antenna direction and/or location. • Check your cable input. • Make sure the cable from your antenna to your TV is connected properly.
Interference: Sharp lines across the screen and unclear sound.	*The following may cause image problems or distortion: Electrical appliances, powerful lights, cars, trucks; computers or portable phones; medical equipment* • If possible increase the distance between your TV and the offending appliance or shut one of them off.
Normal picture but no sound.	• Check sound level. • Make sure the TV sound is not muted. • Try another channel. The problem may be with the broadcast, not your TV. • Are the Audio cables connected properly? • Are the wires for external speakers (if you have external speakers) connected properly? • Make sure your speakers are turned on inthe Audio menu. • If your audio mode is set to SAP, that channel may not have an SAP program.
No picture and unclear sound.	• Are you in TV or cable tuning mode, and should be in the other? • Make sure output channels on all A/V equipment are on the same channel (3 or 4). • Check that all connections are tight.
No picture and no sound.	• Is the AC power cord plugged in? • Check that your AC power outlet works. (Test it by plugging in something else or try another outlet.) • Make sure your brightness and audio controls are set properly. • Try another channel. The problem may be with the broadcast.
No color, but the sound is O.K.	• Check the color settings in the Video menu. • Try another channel. The problem may be with the broadcast.
Picture has a big black box on it, but the sound is O.K.	• The Caption option may be in Text mode. Select Caption 1, or OFF in the Captions/Text menu.
Picture has two horizontal black bars, one on top and one on bottom.	• Your program is in letterbox. This means that the shape of your TV is a square, but the program is a rectangle. Think of the bars as empty space the program doesn't fill; not picture that's blocked out. Because this format is a direct representation of film as you see it in the movies, you are actually seeing MORE of the program when you see those bars.
Missing Secret code	• If you forget the secret code, press the remote control Button '7', '7', '7' and '7' when the display asks you to enter the secret code.

Downloaded from www.Manualslib.com manuals search engine

Remote control doesn't work.	• Make sure the batteries are fresh and installed properly.
Menu options can't be changed or selected.	• Try unplugging your TV for a few minutes, then plug it back in.
No picture or sound when any non-cable source is selected.	• Check to see if the source equipment has been turned on. • Make sure that the connections are secure on the back of your TV and on the source equipment.
Weak or no Stereo Sound when using a stereo VCR.	• Check to see if all the connections are secure. • Look in the Audio mode menu to see if all the settings are correct. • You are using channel 3 or 4 to view your VCR. No stereo sound is present under that decision.
The PIP inset is black or lacks contrast.	• Check to be sure that the PIP source is turned on. • You might want to adjust the PIP picture settings under the PIP menu. • Check that all the wires are connected properly. • Check to see if your input source for PIP is set correctly.
The PIP inset is "snow" when the source is Antenna.	• Look to see if the TV/VCR button on your VCR has the TV selected or change the PIP to another source.
Time is incorrect.	• Reset clock manually.

Downloaded from www.Manualslib.com manuals search engine

Glossary

A list of definitions for some of the words found in this guide as they relate to these TVs.

75 OHM RF CABLE — The round cable that comes from an off-air antenna or cable service provider. Each end looks like a hex shaped nut with a wire sticking through the middle, and it screws onto the threaded jack on the back of your TV.

A/V CABLES — Audio/Video cables. Three cables - Right audio (red), Left audio (white), and Video (yellow). A/V cables are used for stereo playback of videocassettes and for higher quality picture and sound from other A/V devices.

A/V DEVICE — Any device that produces video or sound (VCR, DVD, cable box, satellite receiver, set-top box, or television).

ADD (SHOW) — This function lets you add new channels to the channel list in memory that you'll scroll through when using your remote.

AMPLIFIER — An external device that amplifies sound from a television, CD player, VCR, DVD, or other A/V device.

ANALOG TV — Traditional method of representing a television signal as a replica (analog) of the original picture and sound.

ANTENNA — The physical receiver of television signals sent over the air. A large metal piece of equipment does not always have to be visible for your home to be using an antenna.

ASPECT RATIO — The ratio of the horizontal dimension to the vertical dimension of a picture. Standard television in the U.S. today is generally transmitted and displayed in a 4:3 aspect ratio. High-Definition television will normally be formatted in the wider 16:9 aspect ratio.

AUDIO CENTER MODE IN — Input jack provided for connecting external Dolby digital preamplifier output to the TV, to use as the center speaker channel and enhance your home theater setup.

CAPTIONS — A form of subtitling that writes out the dialog of a program on the screen.

COMPONENT INPUT (P_R P_B Y) — Series of input jacks provided for extremely accurate picture reproduction yielding a higher quality picture than standard video inputs.

DELETE (HIDE) — Removes channels that you don't watch from the channel list in memory.

DIGITAL TV — A new method of representing a television signal as a series of binary numbers (1s and 0s). This method allows for the signal to be manipulated to eliminate redundancy and dramatically increase picture and sound quality.

DOLBY DIGITAL — Dolby Digital Cinema Sound is made possible by a new digital coding technique called Dolby AC-3. Dolby AC-3 produces high-quality, 5.1 channel surround sound which is six discrete separate channels for a full range of sound. Each channel can carry a different signal simultaneously (front center, front left, front right, surround left, surround right and subwoofer).

DVD — Optical disc storage technology. Digital video disc player. A disc that contains movies etc. in digital format.

DVI INPUT — Digital video interface. Video multimedia standard for computer text and graphics. Port for DVI connector.

DTV — Digital television source, (set-top box).

DTV FORMATS

480I — Standard DTV format.
480p — Enhanced DTV format.
720p/1080i — (HDTV) High definition video formats.

Downloaded from www.Manualslib.com manuals search engine

Glossary (Contd.)

A list of definitions for some of the words found in this guide as they relate to these TVs.

HD-STB	High-definition set-top box.
INPUT	Refers to the jack that receives a signal into the TV, VCR or other A/V device.
JACK	A connection on the back of a TV, VCR, or any other A/V device. This includes the RF jacks and the Audio/Video jacks that are color-coded.
MODE	The mode determines the type of device (TV, VCR, Cable, HDSTB) that the remote is controlling; remote operating mode.
MONO SOUND	Mono (monaural) sound is one channel of sound. On more than one speaker all the speakers play the same audio.
OUTPUT	Refers to the jack that sends a signal out of a VCR, DVD, or other A/V device.
PC	A computer.
PIP	This is the most common way to refer to the Picture-in-Picture (PIP) feature.
PIP SNAPSHOT	Press FREEZE button to capture and freeze sub picture in PIP or split mode. Press PIP button to enter PIP mode from another channel. Press EXIT button to remove PIP from the screen.
POP (PICTURE-OUTSIDE-PICTURE)	Additional PIP-type viewing feature.
RGB INPUT	Red, green, blue. 15-pin input provided for computers or set-top boxes.
SECOND AUDIO PROGRAMMING/SAP	Second Audio Programming (SAP) is another, separate, audio channel available with some programming. Choosing SAP often refers to listening to audio in another language, such as Spanish or French.
SIGNAL	Picture and sound traveling through cable, or on the air, to your television screen.
SOURCE	The term for the equipment that provides audio and video information to your TV. Antennas, VCRs, DVD players, and Cable Boxes are examples of sources.
STEREO SOUND	Stereo (stereophonic) sound refers to audio that's divided into right and left sides.
SURF	This function creates a customized list of your favorite channels. You can access this group of channels with the surf button on the remote by pressing Surf repeatedly.
S-VIDEO	(Y-C) connection available for S-Video devices providing better picture quality than standard video inputs.
TEXT	Arbitrary text not related to the program.
TUNER	Any device that picks up broadcast signals and turns them into picture and sound.
TWIN PICTURE	Feature that splits the screen and places two picture sources side-by-side.
XGA	A high-resolution computer data format compatible with these TVs.

Downloaded from www.Manualslib.com manuals search engine

Product Specifications

Models	RU-48SZ40
	Horizontal Size (Inches) 45.5 Height (Inches) 32.9 Depth (Inches) 15.3 Weight (lbs.) 68.3
Power Requirement	AC 120V, 60Hz
Television System	American TV Standard, NTSC, ATSC with STB
Television Channels	VHF: 2 - 13 UHF: 14 - 69 CATV: 1 - 125
Power Consumption (W)	250W
Antenna	75 ohm External Terminal for VHF/UHF
Audio Output (W)	15W x 2
Supplied Accessories	Remote control, 2 size AA batteries.
External Input/Output Ports	Audio/Video inputs (3 sets) Audio/Video output (1 set) S-Video inputs (2) Component inputs (2 sets) RGB input (1) DVI input (1) RGB/DVI audio input (1 set) Variable audio output (1 set) Audio center mode input (1) Calibration port (1) External Speaker output (1 set)

Design and specifications are subject to change without prior notice.

Downloaded from www.Manualslib.com manuals search engine

Notes

Downloaded from www.Manualslib.com manuals search engine

Notes

Downloaded from www.Manualslib.com manuals search engine

(Warranty Contd.)

CONCERNING PIXEL FUNCTIONALITY: Your LCD Rear Projection Television contains about 921600 individual pixels. LCD Projection displays typically contain a small number of pixels that do not function normally. Your display has been inspected and is in compliance with manufacturer's specifications, indicating that any pixel defects do not effect the operation or use of your display.

READ YOUR OPERATING GUIDE CAREFULLY SO THAT YOU UNDERSTAND THE OPERATION OF YOUR LCD REAR PROJECTION DISPLAY AND HOW TO ADJUST THE CONSUMER CONTROLS.

IMPORTANT: Please fill out and mail in your Product Registration Card or go to www.lgservice.com to register your product online. This information allows us to reach you promptly should we discover a safety or reliability problem that could affect you.

CUSTOMER ASSISTANCE NUMBERS

To obtain customer assistance, product information, or Dealer or Service locations	**Call 1-201-816-2000 24 hours a day, 365 days per year**

FOR SERVICE:
For warranty service information, please contact the LG®Brand Customer Support telephone number listed below.

When calling for service, please have your product model number, serial number and the date of purchase or the date of original installation available.

If a replacement unit is required, under some circumstances you may be asked to provide a reserve deposit to the LG®Brand Service Center against a credit card number as surety for advanced shipment. Your credit card will not be charged if you return the defective unit within 10 working days.

If a replacement unit is received, please use the carton and packaging from that unit in returning the defective unit to the LG®Brand Service Center.

Parts and service in accordance with the LG®Brand warranty is our responsibility and will be provided without charge. Other service requirements will be at the owner's expense. If you have problems in obtaining satisfactory warranty service, write or call the LG®Brand Customer Interactive Service.

To assure proper credit and avoid unnecessary charges, you must obtain a Return Authorization before returning any product to the Factory Service Center. Contact the number below or your authorized LG®Brand repair facility for details.

Before you call for warranty service, check your operating guide – you may avoid a service call.

LG Customer Interactive Center
P. O. Box 240007
201 James Record Road
Huntsville, Alabama 35824
ATTN: CIC

Telephone number: 1-201-816-2000
This number is a toll-free number
Follow menu prompts when the call is answered

Web address: www.lgservice.com

Telephone Center Hours of Operation:
24 hours a day, 365 days per year

Service for your LG®Brand Rear Projection Television is provided through LG Electronics Alabama, Inc., the authorized LG®Brand Service Center for the United States.

LG®Brand LCD Rear Projection Televisions are marketed and distributed in the United States by
LG Electronics Corporation, 201 James Record Road Huntsville, Alabama 35824.

Downloaded from www.Manualslib.com manuals search engine

LG® Brand
LCD Rear Projection Television
U.S. Limited Warranty

Your LG® brand LCD Rear Projection Television will be repaired or replaced as set forth below, if it proves to be defective in material or workmanship under normal use, during the warranty period ("Warranty Period") listed below, effective from the date ("Date of Purchase") of original consumer purchase of the product. This warranty is good only to the original purchaser of the product and effective only when used in the United States, excluding U.S. Territories.

WARRANTY PERIOD:

LABOR: One Year from the Date of Purchase. Your unit will be repaired or replaced with a new, substitute model or factory reconditioned unit, at the manufacturer's option. If repair, parts used in the repair may be new or remanufactured.

Parts, except for Halogen Bulb: One Year from the Date of Purchase.

Halogen Bulb: 90 Days from the Date of Purchase.

Replacement Units and Repair Parts are warranted for the remaining portion of the original unit's warranty period.

EFFECTIVE DATE OF WARRANTY: Your warranty period begins on the date of sale to the original consumer / end user. KEEP THE DEALER'S DATED BILL OF SALE OR PROOF OF DELIVERY as evidence of the purchase date. You will be required to submit a legible copy of your bill of sale or proof of delivery when requesting warranty service.

In-Home Service is available on this Unit, as provided in this Warranty. Please retain dealer's dated bill of sale or delivery ticket as evidence of the Date of Purchase for proof of warranty, and submit a copy of the bill of sale to the service person at the time warranty service is provided.

Please call
1-201-816-2000

To locate your nearest LG® Brand Authorized Service Center and to schedule a service appointment.

For further Instructions, see "For Service" below

THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT ANY IMPLIED WARRANTY IS REQUIRED BY LAW, IT IS LIMITED IN DURATION TO THE EXPRESS WARRANTY PERIOD ABOVE. NEITHER THE MANUFACTURER NOR ITS U.S. DISTRIBUTOR SHALL BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY NATURE, INCLUDING WITHOUT LIMITATION, LOST PROFITS, LOST OR CORRUPTED PROGRAMMING OR DATA, OR ANY OTHER DAMAGE WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above exclusion or limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

THIS LIMITED WARRANTY DOES NOT APPLY TO:

- damage caused in shipping or transit
- service required as a result of improper installation, including incorrect or insufficient AC supply (please consult the owner's manual for power supply requirements).
- installation or repair of antenna systems, cable converters, cable company supplied equipment, or other components in a video system
- set-up or adjustment on consumer controls, or damage caused by improper adjustments
- damage caused by other system components
- any unit that has been modified or incorporated into any other product
- replacement of batteries on the remote control.
- replacement of the Halogen Bulb except within the first 90 days
- damage (including cosmetic damage), failure, loss or personal injury due to misuse, abuse, negligence, improper maintenance or storage, or to acts of nature or other causes beyond our control. (Causes beyond our control include but are not limited to lightning strike, power surges, power outages and water damage.)
- repair or replacement of warranted parts by other than an LG® Brand authorized service centers.
- units purchased or serviced outside of the U.S.A.
- product where the original factory serial numbers have been removed, defaced or changed in any way.
- product sold and labeled as "as is, where is" or similar disclaimer.

The cost of repair or replacement under these excluded circumstances shall be borne by the consumer.

P/N : 3828VA0480B

Downloaded from www.Manualslib.com manuals search engine